



ITEM NO.	DESCRIPTION	PART OR IDENTIFYING NO.	QTY. REQ.
1	INLET BUSHING	180-1	1
2	HOSE NIPPLE	1110A-62	1
3	HOSE ADAPTOR	1110A-22	1
4	CAP SCREW	Z-832-160	4
5	WASHER	HSW-40	4
6	OUTER PIPE	1110-9	1
7	PIPE BUSH	1110-17	2
8	O-RING	P-4	3
9	CAP SCREW	Z-M30-80	2
10	STEEL BALL	SB--1/8	2
11	REGULATOR SPRING	450-45	2
12	LEVER	1110-4	2
13	VALVE NUT	1110-21	2
14	AIR VALVE	1110A-18	1
15	O-RING	P-7	1
16	VALVE BUSH	1110A-20	1
17	WATER VALVE	1110A-19	1
18	VALVE HOUSING	1110R-2	1
19	GASKET	1110R-3	1
20	ROLL PIN (2.5 Ø - 4MM)	25-4	1
21	REAR CASE	1110A-5	1
22	BEARING CAP	680-34	1
23	RETAINING RING	JS-6	1
24	BALL BEARING	626	1

ITEM NO.	DESCRIPTION	PART OR IDENTIFYING NO.	QTY. REQ.
25	REAR PLATE	1110-26A	1
26	ROLL PIN (2.5 Ø - 4MM)	25-5	2
27	CYLINDER	1110-24A	1
28	ROTOR BLADE	1110R-8	5
29	ROTOR	1110R-7	1
30	FRONT PLATE	1110R-6	1
31	BALL BEARING	608-ZZ	1
32	RETAINING RING	JS-15	2
33	WAVE WASHER	WW-150	2
34	BALL BEARING	6002	2
35	PINION GEAR	1110A-12	1
36	RETAINING RING	1E-8	1
37	MOTOR HOUSING	1110R-1A	1
38	CAP SCREW	Z-832-160	2
39	PIPE CONNECTOR	1110-3A	1
40	INNER PIPE	1110-23	1
41	O-RING	S-12	1
42	OIL SEAL	G8-14-4	1
43	O-RING	S-7	1
44	GREASE PLUG	1110A-6	1
45	BALL BEARING	608-LLU	1
46	BEVEL GEAR	1110A-13	1
47	BALL BEARING	6302-LLU	1
48	SPINDLE (5/8")	1110A-11U	1
49	KEY	940-46	1
50	OIL SEAL	G23-32-7	1
51	SPINDLE CAP	1110-15	1
52	NOZZLE	1110A-16	1
53	DEAD HANDLE (OPTION)	240B-2	1
54	SPANNER WRENCH (14 X 19MM)	350-28	1
55	HANDLE	1110R-4	1
56	BOLT	1110R-5	2
57	WIPE HOSE	106-3	1
58	EXHAUST COVER	106-5	1
59	CONNECTOR	106-6	1
60	URETHANE BAND	106-1	1
61	EXHAUST HOSE	106-2	1
62	HARNESS BAND	106-10	1
63	WATER HOSE JOINT	1110A-61	1
64	WATER HOSE	1110A-64	1
65	O-RING	S-8	1
66	HOUSING COVER	1110A-67	1